



PC Connect Cable - stereo plug tip wired to DB-9 female pin 2
 stereo plug ring wired to DB-9 female pin 3
 stereo plug base wired to DB-9 female pin 5

EDC-D10 Cable - replace XXX1, etc with colours of actual wire used